


5 4 3 2 1
MICROROC is dedicated chip for GEM/MICROMEAS. MICROROC(pin pin compatible with HR2b) is based on HR2b same back-end, same readout format, same pinout, only the preamplifier is changing
Dynamic range 1fC~500fC



The GEM detector is designed as 37cm*37cm, and its effective area is 30cm*30cm. Each Microroc ASIC has 64 readout channels. That is to say some of Microrocs cannot be full used and the unused pin should tied to GND via a capacitor. The ESD protection is necessary as there might be spark in the GEM.




There are 3 kinds of control signals
1. Daisy chain signals: sr_in, sr_out, start_readout, end_readout
2. Independent signal for each chain: Dout1b, Dout2b, TransmitOn1b, TransmitOn2b, ChipSatb, TrigExt, StartAcq, StartReadout1, StartReadout2, sr_rstb, sr_ck, sr_in, EndReadout1, EndReadout2, sr_out
3. Common signals for all chains: 4 LVDS signals, power on signals, reset_b, rst_counterb, select, hold, out_trigger0~2b
FPGA LVDS driver can handle directly many ASICs (6-10) for sure. But if there is more ASICs, you should use more than 1 dedicated LVDS drivers. In this design, M-LVDS buffer is used

SDHCal FEB


SDHCal FEBVersion: 1.0Design Tools:
Cadence 16.6Finish Date: 2018/01/27
Engineer: Yu WangCompany: USTC


Tips: If there is gibberish, please install the 'Input' font, 'Romantic' font and 'Celestina' font.
Note:All the Title and Document Number is Input, blod, size 10.Rev is Input, size 6.
All the comments is Input, blue size 6
Note: All the unsolder package should value x(Not F)
Capacitor: F(Not F)

Title		
SDHCal FEB		
Size	Document Number	Rev
A4	Design Info	v1.0
Date:	Monday, January 22, 2018	Sheet 1 of 48




Title		
SDHCal FEB		
Size	Document Number	Rev
A4	Design Structure	v1.0
Date:	Monday, January 22, 2018	Sheet 2 of 48





2
1
Although the each channel of MICROROC has a spark protection network, it's recommended to add external protection circuit. BAV99W is a choice but may not be the best!





GEM_In1	R1	100	ESD_Signal1	C1	10nF AnalogIn1
GEM_In5	R5	100	ESD_Signal5	C5	10nF AnalogIn5
GEM_In9	R9	100	ESD_Signal9	C9	10nF AnalogIn9
GEM_In13	R13	100	ESD_Signal13	C13	10nF AnalogIn13
GEM_In17	R17	100	ESD_Signal17	C17	10nF AnalogIn17
GEM_In21	R21	100	ESD_Signal21	C21	10nF AnalogIn21
GEM_In25	R25	100	ESD_Signal25	C25	10nF AnalogIn25
GEM_In29	R29	100	ESD_Signal29	C29	10nF AnalogIn29
GEM_In33	R33	100	ESD_Signal33	C33	10nF AnalogIn33
GEM_In37	R37	100	ESD_Signal37	C37	10nF AnalogIn37
GEM_In41	R41	100	ESD_Signal41	C41	10nF AnalogIn41
GEM_In45	R45	100	ESD_Signal45	C45	10nF AnalogIn45
GEM_In49	R49	100	ESD_Signal49	C49	10nF AnalogIn49
GEM_In53	R53	100	ESD_Signal53	C53	10nF AnalogIn53
GEM_In57	R57	100	ESD_Signal57	C57	10nF AnalogIn57
GEM_In61	R61	100	ESD_Signal61	C61	10nF AnalogIn61


GEM_In2	R2	100	ESD_Signal2	C2	10nF AnalogIn2
GEM_In6	R6	100	ESD_Signal6	C6	10nF AnalogIn6
GEM_In10	R10	100	ESD_Signal10	C10	10nF AnalogIn10
GEM_In14	R14	100	ESD_Signal14	C14	10nF AnalogIn14
GEM_In18	R18	100	ESD_Signal18	C18	10nF AnalogIn18
GEM_In22	R22	100	ESD_Signal22	C22	10nF AnalogIn22
GEM_In26	R26	100	ESD_Signal26	C26	10nF AnalogIn26
GEM_In30	R30	100	ESD_Signal30	C30	10nF AnalogIn30
GEM_In34	R34	100	ESD_Signal34	C34	10nF AnalogIn34
GEM_In38	R38	100	ESD_Signal38	C38	10nF AnalogIn38
GEM_In42	R42	100	ESD_Signal42	C42	10nF AnalogIn42
GEM_In46	R46	100	ESD_Signal46	C46	10nF AnalogIn46
GEM_In50	R50	100	ESD_Signal50	C50	10nF AnalogIn50
GEM_In54	R54	100	ESD_Signal54	C54	10nF AnalogIn54
GEM_In58	R58	100	ESD_Signal58	C58	10nF AnalogIn58
GEM_In62	R62	100	ESD_Signal62	C62	10nF AnalogIn62


GEM_In3	R3	100	ESD_Signal3	C3	10nF AnalogIn3
GEM_In7	R7	100	ESD_Signal7	C7	10nF AnalogIn7
GEM_In11	R11	100	ESD_Signal11	C11	10nF AnalogIn11
GEM_In15	R15	100	ESD_Signal15	C15	10nF AnalogIn15
GEM_In19	R19	100	ESD_Signal19	C19	10nF AnalogIn19
GEM_In23	R23	100	ESD_Signal23	C23	10nF AnalogIn23
GEM_In27	R27	100	ESD_Signal27	C27	10nF AnalogIn27
GEM_In31	R31	100	ESD_Signal31	C31	10nF AnalogIn31
GEM_In35	R35	100	ESD_Signal35	C35	10nF AnalogIn35
GEM_In39	R39	100	ESD_Signal39	C39	10nF AnalogIn39
GEM_In43	R43	100	ESD_Signal43	C43	10nF AnalogIn43
GEM_In47	R47	100	ESD_Signal47	C47	10nF AnalogIn47
GEM_In51	R51	100	ESD_Signal51	C51	10nF AnalogIn51
GEM_In55	R55	100	ESD_Signal55	C55	10nF AnalogIn55
GEM_In59	R59	100	ESD_Signal59	C59	10nF AnalogIn59
GEM_In63	R63	100	ESD_Signal63	C63	10nF AnalogIn63

GEM_In4	R4	100	ESD_Signal4	C4	10nF AnalogIn4
GEM_In8	R8	100	ESD_Signal8	C8	10nF AnalogIn8
GEM_In12	R12	100	ESD_Signal12	C12	10nF AnalogIn12
GEM_In16	R16	100	ESD_Signal16	C16	10nF AnalogIn16
GEM_In20	R20	100	ESD_Signal20	C20	10nF AnalogIn20
GEM_In24	R24	100	ESD_Signal24	C24	10nF AnalogIn24
GEM_In28	R28	100	ESD_Signal28	C28	10nF AnalogIn28
GEM_In32	R32	100	ESD_Signal32	C32	10nF AnalogIn32
GEM_In36	R36	100	ESD_Signal36	C36	10nF AnalogIn36
GEM_In40	R40	100	ESD_Signal40	C40	10nF AnalogIn40
GEM_In44	R44	100	ESD_Signal44	C44	10nF AnalogIn44
GEM_In48	R48	100	ESD_Signal48	C48	10nF AnalogIn48
GEM_In52	R52	100	ESD_Signal52	C52	10nF AnalogIn52
GEM_In56	R56	100	ESD_Signal56	C56	10nF AnalogIn56
GEM_In60	R60	100	ESD_Signal60	C60	10nF AnalogIn60
GEM_In64	R64	100	ESD_Signal64	C64	10nF AnalogIn64











D


C


B

A











D


C

B

A









D


C


B


A





























GEM_In1	R1250	100	ESD_Signal1	C1308	10nF AnalogIn1
GEM_In5	R1254	100	ESD_Signal5	C1310	10nF AnalogIn5
GEM_In9	R1258	100	ESD_Signal9	C1314	10nF AnalogIn9
GEM_In13					AnalogIn13
GEM_In17					AnalogIn17
GEM_In21	R1270	100	ESD_Signal21	C1326	10nF AnalogIn21
GEM_In25	R1274	100	ESD_Signal25	C1330	10nF AnalogIn25
GEM_In29	R1278	100	ESD_Signal29	C1334	10nF AnalogIn29
GEM_In33					AnalogIn33
GEM_In37					AnalogIn37
GEM_In41					AnalogIn41
GEM_In45					AnalogIn45
GEM_In49					AnalogIn49
GEM_In53	R1302	100	ESD_Signal53	C1358	10nF AnalogIn53
GEM_In57	R1306	100	ESD_Signal57	C1362	10nF AnalogIn57
GEM_In61					AnalogIn61


GEM_In2	R1251	100	ESD_Signal2	C1307	10nF AnalogIn2
GEM_In6	R1255	100	ESD_Signal6	C1311	10nF AnalogIn6
GEM_In10	R1259	100	ESD_Signal10	C1315	10nF AnalogIn10
GEM_In14					AnalogIn14
GEM_In18	R1267	100	ESD_Signal18	C1323	10nF AnalogIn18
GEM_In22	R1271	100	ESD_Signal22	C1327	10nF AnalogIn22
GEM_In26	R1275	100	ESD_Signal26	C1331	10nF AnalogIn26
GEM_In30					AnalogIn30
GEM_In34					AnalogIn34
GEM_In38					AnalogIn38
GEM_In42					AnalogIn42
GEM_In46					AnalogIn46
GEM_In50	R1299	100	ESD_Signal50	C1355	10nF AnalogIn50
GEM_In54	R1303	100	ESD_Signal54	C1359	10nF AnalogIn54
GEM_In58	R1307	100	ESD_Signal58	C1363	10nF AnalogIn58
GEM_In62					AnalogIn62

GEM_In3	R1252	100	ESD_Signal3	C1308	10nF AnalogIn3
GEM_In7	R1256	100	ESD_Signal7	C1312	10nF AnalogIn7
GEM_In11	R1260	100	ESD_Signal11	C1316	10nF AnalogIn11
GEM_In15	R1264	100	ESD_Signal15	C1320	10nF AnalogIn15
GEM_In19					AnalogIn19
GEM_In23	R1272	100	ESD_Signal23	C1328	10nF AnalogIn23
GEM_In27	R1276	100	ESD_Signal27	C1332	10nF AnalogIn27
GEM_In31	R1280	100	ESD_Signal31	C1336	10nF AnalogIn31
GEM_In35	R1284	100	ESD_Signal35	C1340	10nF AnalogIn35
GEM_In39					AnalogIn39
GEM_In43					AnalogIn43
GEM_In47					AnalogIn47
GEM_In51	R1300	100	ESD_Signal51	C1356	10nF AnalogIn51
GEM_In55	R1304	100	ESD_Signal55	C1360	10nF AnalogIn55
GEM_In59	R1308	100	ESD_Signal59	C1364	10nF AnalogIn59
GEM_In63					AnalogIn63


GEM_In4	R1253	100	ESD_Signal4	C1309	10nF AnalogIn4
GEM_In8	R1257	100	ESD_Signal8	C1319	10nF AnalogIn8
GEM_In12	R1261	100	ESD_Signal12	C1317	10nF AnalogIn12
GEM_In16					AnalogIn16
GEM_In20					AnalogIn20
GEM_In24	R1273	100	ESD_Signal24	C1329	10nF AnalogIn24
GEM_In28	R1277	100	ESD_Signal28	C1339	10nF AnalogIn28
GEM_In32					AnalogIn32
GEM_In36					AnalogIn36
GEM_In40					AnalogIn40
GEM_In44					AnalogIn44
GEM_In48					AnalogIn48
GEM_In52	R1301	100	ESD_Signal52	C1357	10nF AnalogIn52
GEM_In56	R1305	100	ESD_Signal56	C1367	10nF AnalogIn56
GEM_In60	R1309	100	ESD_Signal60	C1365	10nF AnalogIn60
GEM_In64					AnalogIn64



D




C




B


A

Title		
SDHCal FEB		
Size	Document Number	Rev
A4	ASIC E Reserved	V1.0
Date:	Monday, January 22, 2018	Sheet 36 of 48






5




4

The B pins is forward to the innner side of board



2






1



Warning: The male connector and female connector has different footprint and package.
The A1 pin of male connector is connected to the A1 pin of female connector, B1(male) connect to B1(female) ...
Note that this is different from ECal system but the signal connection is the same.

Female connector ERNI154744 on FEB
 Male connector ERNI 154767 on DIF








Title		
SDHCal FEB		
Size	Document Number	Rev
A3	Interface To DAQ	V1.0
Date:	Wednesday, January 24, 2018	Sheet 39 of 48

D

C

B

A



hold

select

reset_b

rst_counterb

pwr_on_d

pwr_on_a

pwr_on_adc

pwr_on_dac

hold

select

reset_b



rst_counterb

pwr_on_d

pwr_on_a

pwr_on_adc

pwr_on_dac



Title		
SDHCal FEB		
Size	Document Number	Rev
A4	Signal Distributor-- LVCMOS Driver	V1.0
Date:	Monday, January 22, 2018	Sheet 40 of 48

D

C

B

A

5







4

3


2

1

Driver enable pins:
When DE is low, the
driver is disabled.
When DE is high, the
driver is enabled.
There is a 300k ohm
pulldown resistor on
each pin.



Title		
SDHCal FEB		
Size	Document Number	Rev
A4	Signal Distributor--LVDS Buffer	V1.0
Date:	Monday, January 22, 2018	Sheet 41 of 48



5 4 3 2 1

This part is the readout array of GEM detector. The effective area of the GEM detector is 30cm*30cm, and the total size is 37.4*37.4. The detail structure of the Pad Readout Array is discribed in the Mechanical structure of Pad Readout Array.pdf



D


C


B


A

Title			
<Title>			
Size	Document Number		Rev
A4	<Doc>		<Rev>
Date:	Monday, January 22, 2018	Sheet	43 of 48















DC Jack




Analog Power



Digital Power



Caution: If using ECal DIF, only VCC5.0V_BOARD_IN is available



Title		
SDHCal FEB		
Size	Document Number	Rev
A4	Analog Power	V1.0
Date:	Friday, January 26, 2018	Sheet 48 of 48